



TOMAHAWK USA

Replacement Filter Installation Instructions Flushing of Pre-Filters for FMV5: Waterboy R.O. System

1. Unscrew the two blue filter housings
2. Remove and replace filters:
Micron paper filter on the left filter housing which has the garden hose water inlet fitting.
Carbon filter on the right filter housing which has the ½" blue tubing coming out the outlet fitting.
3. Once the filter housings are screwed back on, follow the blue ½" outlet tube from the carbon filter housing and disconnect from the membrane element housing.
4. Once disconnected from the membrane element housing, it's time to flush the filters. Hook up the water supply to the water inlet fitting and run water through the blue filter housings for roughly 3 minutes, or until the water becomes clear when collected in a cup. When no black carbon dust can be seen in the water anymore, flushing is complete and you can hook up the blue ½" tubing back into the membrane element.

**** Flushing of the carbon filter is very important prior to connecting the ½" blue tubing back to the membrane element housing! If carbon dust enters the membrane, it will foul the membrane element.**